

PURE

PLANK REPLACEMENT PROCEDURE



Adjust circular saw to the depth of the LVT board and cut the plank lengthwise along its center axis;



Carefully make radial cuts from the central cut to the 4 corners of the plank, making sure not to cut or otherwise damage the adjoining boards;





Pry the first plank section loose by inserting a putty knife in the cut running down the center of the plank. Gently unclick the first plank section from the adjoining planks;

Remove the other sections of the plank by unclicking them;





Remove the tabs on both long sides of the replacement plank;
Leave the tabs on the short sides;

Go back to the area where you removed the plank;
Apply glue on the tabs now visible along both the long and the short sides;





Insert the replacement plank at the short end by clicking it into the tabs of the plank already on the floor;



Fit the plank into the tabs at the other short end of the opening created by flexing it into place;



Push the replacement plank all the way down;

PURE

15



Place a heavy weight on the newly inserted plank and allow to cure undisturbed for 24 hours;

16



The end result.